

Wire Connectors

Installation Instructions

Model **P15** Qty **250 PCS**

To be sold only with installation instructions

Installation Instructions:

- 1. Turn off power before installing or removing connectors.
- 2. Strip wires 3/4" (19.1 mm).
- 3. Pre-twisting unnecessary, hold stripped wires together with ends even. Lead stranded wires slightly.
- 4. Align any frayed strands or conductors.
- 5. Push wires into connector and screw on until two twists are visible in wires.

FOR USE WITH COPPER TO COPPER

Temperature Rating: 105°C (221°F) Max.

Voltage Rating: 600V Max. building wiring; 1000V Max. in fixtures and signs

Listed as a Pressure-Type Wire Connector on the following **Solid** and/or **Stranded** wire combinations:

For UL Listed

3 #14 w/1 or 2 #16
3 #14 w/1 or 2 #18
4 #14 w/1 #16
4 #14 w/1 #18



For CSA and CQC Certified

i or oomana ogo continica	
2 or 3 #10	3 #12 w/1 #14 or #16
3 or 4 #12	3 #14 w/1 or 2 #16 or #18
1 #10 w/3 #18	4 #14 w/1 #16 or #18
1 #10 w/2 to 4 #12 or #14	1 #8 w/1 or 2 #10
3 #10 w/1 or 2 #14 or #16	1 #8 w/1 to 4 #16 or #18





Warranty limited solely to repair or replacement; no warranty of merchantability, fitness for a particular purpose or consequential damages



MADE IN CHINA

3 #12 w/1 or 2 #14, #16 or #18